



## End of Line Testing Procedure

1. Hook up computer and Jpro as they always have.
2. Connect Air
3. Turn on Brake power
  - a. Listen for 3 air chuffs, validates valve
4. Turn off Brake power
5. Turn on Aux Power
  - a. Listen for 3 air chuffs, validates valve
  - b. Look at Jpro and see PLC flashing and ABS lamp go on and off, validates PLC
2. Look at Lamp at side of trailer
  - a. Should go on and off
2. Go to wireless networks on PC
  - a. Verify address is same as on sticker
  - b. Connect, open browser, and follow procedure to see ABS information in browser
2. ABS OK, good to go
3. If issue, browser information will assist in trouble shooting